



**PART #M31023**

## 2011 Mustang GT, Axle-Back Exhaust

### **PACKING LIST**

*Before installation, use this checklist to make sure all necessary parts have been included.*

ITEM	QTY	PART NUMBER	DESCRIPTION
1.	1	310803787	Tail Pipe, Rear DS, '11-'14
2.	1	310803788	Tail Pipe, Rear, PS, '11-'14
3.	2	310305080	Tip, 4" OD, 2.5" Inlet, Polished, Slash Cut
4.	2	308144380	Clamps, Torca, 2.5"

**WARNING: SLP Recommends allowing the vehicle to cool (not running) for five hours before beginning installation**

**INSTALLATION INSTRUCTIONS – # M31023**

1. Raise and fully support the vehicle (a vehicle lift is recommended). If you do not have access to a lift, you may raise the rear using a jack/jackstands or by using drive-up type ramps.
2. Loosen the 2 factory bell/band clamps near the rear axle and remove the factory exhaust system. You may remove the factory rubber isolators but will be reusing them. A few sprays of WD-40 on the isolators makes removal and installation easier.
3. Using a cut-off wheel, cut the weld holding the clamp to the stock muffler. Then remove the clamp, this will be reused during installation.
4. Take a piece of wood about an inch thick and place it between the factory over-axle pipe and the upper panhard bar on each side to allow for adequate clearance when installing the axleback.
5. Place the factory hangers back onto the axleback hangers. Repeat for other side.
6. Place the stock bell/band clamp over the ball flange on the system and raise into place. Insert the isolators onto the hangers on the vehicle. Repeat for other side. See figure 1.



**Figure 1: Installation of DS Muffler Assembly**

7. Place a torca clamp onto the exhaust tip and slide onto muffler assembly / rear tailpipe. Snug clamp but to not fully tighten. Repeat for other side.



S T R E E T   L E G A L   P E R F O R M A N C E

8. Adjust system from front to back to allow for adequate clearance all around and tighten all clamps.
9. Test drive vehicle and inspect for any leaks.
10. The finished installation should look like Figure 2.



**Figure 2: Finished Installation**

11. The installation is now complete. Enjoy!