

## 2015-2018 Mustang UPR Toe Link Instructions

1. Elevate the vehicle and support with jack stands or use car lift if you have access.
2. Remove both rear wheels.
3. Remove the bolt/nut holding the inner side of the factory toe link then the bolt holding the outer side and remove the toe link.
4. Adjust the UPR Toe Link to match the factory toe link as a starting point (see image 2).
5. Install the inner side of the toe link using the square washers to lock in the position of the link.
6. Followed by the outer side of the toe link and tighten to 129ft/lbs.
7. Repeat steps 3-6 on the other side.
8. Re-install the wheels and put the vehicle back on the ground.
9. Adjust your toe to your desired setting with the turnbuckle and lock it into position with the jam nuts when done.

